




R37




电机需配时或配特殊电机时需加联接法兰  
When equipping the user's motor or the special one, the flange is required to be connected.




RF37




R..S37



Φ200



R..37R17



注：其余尺寸见相应的结构形式  
Note: For other values please refer to the opposite structure

Y2电机机座号 Motor size	63	71	80	90S	90L	100L	
功率/4P Power/(kW)	0.18	0.25 0.37	0.55 0.75	1.1	1.5	2.2 3.0	
L3	235	245	278	304	328	340	
G	130	145	175	195	195	215	
L2	71	71	71	71	71	93	

注：“R..”表示R、RF

Note：“R..”mean R、RF

R