




R47





电机需方配时或配特殊电机时需加联接法兰  
When equipping the user's motor or the special one, the flange is required to be connected.




RF47



R..S47



R..47R37



注：其余尺寸见相应的结构形式  
Note: For other values please refer to the opposite structure

Y2电机机座号 Motor size	63	71		80		90S	90L	100	112M	132S	
功率/4P Power/(kW)	0.18	0.25	0.37	0.55	0.75	1.1	1.5	2.2 3.0	4.0	5.5	
L3	223	245		278		304	328	350	380	425	
G	130	145		175		195	195	215	240	275	
L2	81	81		81		81	81	93	93	101	

注：“R..”表示R、RF      Note：“R..”mean R、RF